

Ensure product is located in the

🔲 Neutral - Blue

Earth - Yellow & Green


Switched Live (L1) - Brown

Permanent Live (L2) -Black (for emergency)


correct location and mark the


fixing surface

Installation



Switch OFF at mains supply before installing








10


Change battery switch to 'ON' position




Hold the base securely and twist

to unlock and remove the diffuser

Press the individual terminal and insert the correct incoming supply before releasing the terminal to secure. The product MUST be earthed Note: Please ensure there are no switches, PIRS etc in the permanent live feed, as switching of the emergency pack will reduce the battery's life considerably




Use the CCT selection switch on the gear tray to select the desired colour temperature




Push and twist the diffuser back into place

S17321 - 8W LED CCT Emergency Gear Tray



Pull power supply through hole in the base plate




Use correct drill bit to drill

screw holes

L2

Connect battery pack cable to lamp panel



Return power. Switch ON at mains supply

Packaging Information


	SIZE(CM)	N.W/pc (KGS)	G.W.(KGS)	Q'TY(PCS)
Carton	43*20*40	0.16	4.5	20


	CTNS	Q'TY(PCS)	VOLUME(CBM)
20" standard container	686	13720	28
40" standard container	1480	29600	58





POWER


ASTER











Align gear tray with screws and tighten